



シリーズ詳細



107 84 002
27.5cmディナープレート
D-27.3 H-3.2 ¥3,000



107 84 003
24.5cmミートプレート
D-24.5 H-3 ¥2,300



107 84 004
21cmデザートプレート
D-21 H-2.6 ¥2,100



107 84 006
19.5cmケーキプレート
D-19.6 H-2.3 ¥1,800



107 84 007
17cmプレート
D-17.1 H-2.2 ¥1,500



107 84 008
15cmプレート
D-15 H-1.9 ¥1,100



107 84 046
31cmプラター
L-32 S-22.8 H-4.2 ¥5,200



107 84 047
27cmプラター
L-27.3 S-19.3 H-3.8 ¥4,400



107 84 010
26cmリムスープボウル
D-26 H-4.8 ¥2,700



107 84 012
22.5cmパスタボウル
D-22.6 H-4.6 ¥2,200



107 84 025
14.5cmフルーツボウル
D-14.6 H-3.4 ¥1,500



130 84 050
マグカップ
L-12.2 S-9 H-8
C-295cc ¥1,500



130 84 052
コーヒーカップ
L-10.3 S-7.8 H-6.8
C-200cc ¥1,200

130 84 055
コーヒーソーサー
D-15.2 H-1.9
¥950